

## Access Armor Repair Kit Instructions



**Kit Includes;**  
1 Replacement Gasket  
1 Tube of Kwik Seal  
1 Mini Scraper

### Step 1

**(A) Using provide mini scraper, remove the existing gasket. (B) Make sure to remove any remaining old adhesive.**

**(1) A**



**B**



### Step 2

**(A) Using the provided sealant/adhesive make a bead all the way around the perimeter of the panel. (B) Cover as much area as possible.**

**(2) A**



**B**



**(3)**



### Step 3

**Line up the new gasket using the grease seal gasket as a reference.**

**(4) A**



**B**



### Step 4

**(A) Press the gasket down onto the sealant firmly and evenly. (B) Let the gasket and adhesive set for a minimum of 2 hours before reinstalling the panel to the duct.**