



OmniContainment.ca

2/9/18

Instruction Sheet For Quick Fit Easy Clean Super Hinge Pre-Installation

Make sure there are no obstructions that will be in the way of the mounting area on the fan or duct such as electric boxes, conduits, brackets, etc. Check to be sure that the power supply conduit is in good condition and has adequate length for the fan to be tilted

*Note proper sizing on the attached manufacturer disclaimer page.

SEE REVERSE FOR PARTS DIAGRAM

- 1. Turn off the power supply at breaker box. Set The Hinge with the curb rests on the same side as the fan spout directly below the fan base with the adjustable mounting bracket (AMB) directly lined up with the edge of the FAN BASE on the SPOUT side.
- 2. (A)Once proper alignment has been achieved, slide the quick fit upper arm onto the fan base. (B)Using the supplied 5/16 bolts tighten each bolt until it just starts to pinch the fan base,

Save tightening them completely until final step of the install, as both sides MUST be mounted exactly as the other.

- 3. Position adjustable mounting bracket as high as it can go without breaking contact seal between the fan base and curb. Make sure that the adjustable mounting bracket is level, then attach it to the curb using the provided selftapping screws
- Determine that fan is making complete contact seal with top of duct AND is square and aligned perfectly
- Repeat Steps I-3 for other side.
- Once complete, tighten all Quick fit upper arm bolts on both sides of fan, making sure each side is mounted exactly as the other.
- 4. Slowly lift fan through the illustrated tilting motion to insure there is no binding or miscalculation with both sides being installed EXACTLY the same as the other. When fan hinge properly moves thru the illustrated sequence check and re-tighten all fasteners.

During the transition, utilize two hands to transition, at the highest point on the fan.

NEVER PUT HANDS BETWEEN ANY OF THE HINGE PARTS. DOING SO MAY RESULT IN SERIOUS INJURY, INCLUDING LOSS OF LIMB.







