

Instruction Sheet For Lane Guard

Lane Guard Kit Includes;

- (1) Hydrophobic absorbent mat, (4) Steel hold down cleats, (4) Cleat pavement fasteners, (4) Cleat shims, (1) Disposal bag, 1/4" Drill bit

Pre-Installation

Installation Note: The center of the Lane GuardTM pavement protection system should be installed over the center of the existing spill/stain area on the Pavement.

1) Use Grease AwayTM to clean the spill/application area of grease and oil residue. Once spill area has been properly cleaned lay out absorbent mat in desired area BLACK SIDE UP.

2) Starting with one of the four corners lay the elastic cinch strap flat, extending out from corner of mat. Measure and mark the point 4" beyond the end of the strap.

3) Using the supplied 1/4" drill bit, drill a hole in the pavement approximately 3" deep-USING hammer drill option on drill if available, be sure to drill straight down.

4) Set cleat fastener, cleat, and shim in drilled hole as shown.

5) Set cleat assembly flush to mounting surface, with hooked end of cleat facing absorbent mat elastic cinch strap and set in hole.

6) Strike head of cleat fastener with hammer until striking tip is flush with cleat. Repeat steps 2 - 6 with remaining three corners of mat.

7) Once all four cleats are securely mounted to the pavement, attach all four corners to their elastic cinch straps securing the Lane GuardTM absorbent mat in place. If using for a dumpster, roll or place the dumpster in center of Lane GuardTM system.

Replacement:

The Lane GuardTM Model LG-5596 is capable of containing approximately 5 gallons of spilled waste oils/grease. The Lane GuardsTM combination of absorbent materials are U.V. stable, tear resistant, and hydrophobic (only absorbs oils and grease while repelling water and precipitation). The rolled and seamed perimeter serves as a barrier detouring fluid run off while encouraging full saturation of the pad before replacement is required.

